



TECH BULLETIN

077
7/97

Published regarding engineering changes and improvements

SUBJECT: Oil Drain Kit

To facilitate the draining of the crankcase oil from a CAT PUMP, we now offer an Oil Drain Kit. This will be listed as an “optional” accessory on the pump data sheets.

Simply remove the oil drain plug from the rear crankcase cover and thread in the adapter with o-ring. Then thread in the oil drain hose with barb. The opposite end can be mounted to your equipment enclosure panel with the panel mount adapter or to the L-bracket and then fastened to the mounting base of your unit. Secure the panel mount adapter and thread in the square head plug. Remove the plug when ready to drain the oil. Remember to use teflon tape on all threaded connections.



34334 Oil Drain Kit

- 1—34368 Hose (24" x 3/8")
- 1—25144 Adapter, Drain Plug
- 1—23170 O-Ring, Adapter
- 1—34329 Square Head Plug
- 1—34369 Barb (3/8" x 1/4")
- 1—34338 Panel Mount Nut
- 1—34347 L-Bracket
- 2—990776 Screws (1/4-20) Self Tap.
- 1—34333 Instruction Sheet

CAT PUMPS
Technical Services Department