

# UML SEA SAFETY

## SPARES



Mk 5. 6. 8. + 9.  
Manual Firing Indicator.  
UMO 1622/C



Min Manual  
Firing Indicator.  
UMS 1622/1



Mk 6.8. + Manual Gas Seal.  
IU - UMO 1625 - 02



2004 Mk 5. + Manual.  
Gas Seal Washer.  
UMO 0004/A



Mk 5. 2004 Mk 5.  
Manual. 2004 Manual.  
D - Post O Ring White.  
IU - UMO 16x2N70W - 02.



Mk 6. + Mk 8.  
D - Post O Ring Black  
IU - UMO 16x2N70B - 02.



Standard  
Schrader  
Valve.